Submittal

Job	Designer	Contact	

Smart Mix Expansion 295

The Smart Mix Expansion 295 is designed to operate a mix device within a hydronic heating/cooling system as an expansion to the tekmar Smart Heat Pump Control 291. It is capable of controlling a mixed system pump and optional outputs for mixing: a variable speed injection pump, a floating action actuator, or an analog 0-10 V (dc), or 4-20 mA signal and a diverting valve for switching between hot and chilled water.

9"
(229 mm)

8"
(203 mm)

Side View 211/32" (60 mm)

Features

- Requires a tekmar Smart Heat Pump Control 291
- Powered variable speed injection pump
- Powered 24 V (ac) floating action output
- Analog 4-20 mA
- Analog 0-10 V (dc)
- Powered 120 V (ac) system pump
- Powered 24 V (ac) system pump signal


Specifications


Smart Mix Expansion 295

Call customer support if you need assistance with technical details.

Literature	IOM-T-295, ES-T-295
Packaged weight	2.4 lbs (1.10 kg)
Dimensions	9" H x 8" W x 211/16" D (229 x 203 x 60 mm)
Enclosure	Blue ABS plastic, NEMA type 1
Approvals	CSA C US, FCC Part 15B, CAN ICES-3 (B)/NMB-3(B)
Ambient conditions	Indoor use only, 32 to 122°F (0 to 50°C), < 90% RH non-condensing, Installation Category II, Pollution Degree 2
Power supply	115 V (ac) ±10%, 60 Hz, 6 W
Relays	230 V (ac), 5 A, 1/3 hp
Variable Pump	115V (ac), 2.4A
Modulating Outputs	0-10 V (dc) 500 Ω minimum load impedance or 4-20 mA 1 $k\Omega$ max load impedance
Calls	24 V (ac) or Short
Warranty	Limited 3 Year (See IOM for full warranty)







Legend

AHU1 = Air Handling Unit 1

HP1-HP2 = Heat Pumps 1-2

V1-V2 = 6-Way Diverting Valve Panel 731 or 732

P1-P2 = Heat Pump Pumps 2-3

E1-E2 = Expansion Tanks

P3 = Hot Loop Pump

P4 =Cold Loop Pump

P5 = Variable Speed Injection Pump

P6 = Mix Loop System Pump

S1 = Hot Tank Sensor 082

S2 = Cold Tank Sensor 082

S3 = Hot Tank Return Sensor 082

S4 = Cold Tank Return Sensor 082

S5 = Mix Supply Sensor

Z1 = Radiant Heating Zone Manifold

Z2 = Air Heating Zone Valve

Z3 = Air Cooling Zone Valve

V5-V6 = Globe or Balancing Valve

T1 = Optional Thermostat Heating Call

T2 = Optional Thermostat Cooling Call

tN4-1 = Optional tekmarNet® Call

NOTICE

The information contained herein is not intended to replace the full product installation and safety information available or the experience of a trained product installer. You are required to thoroughly read all installation instructions and product safety information before beginning the installation of this product.



Tel: 1-800-438-3903 • F: (250) 984-0815 tekmarControls.com

ES-T-295 2539 © 2025 tekmar