

# Installation, Operation and Maintenance Manual

## Deringer™ 40G/40GX/50G/50GX

Reduced Pressure Zone/  
Reduced Pressure Detector Assemblies

Size: 40G/50G: 6" & 8"  
40GX/50GX: 4" & 6"



### ⚠ WARNING



Read this manual **BEFORE** using this equipment.

Failure to read and follow all safety and use information can result in death, serious personal injury, property damage, or damage to the equipment.



Keep this manual for future reference.

### ⚠ WARNING

You are required to consult the local building and plumbing codes prior to installation. If the information in this manual is not consistent with local building or plumbing codes, the local codes should be followed. Inquire with governing authorities for additional local requirements.

# Tools Required

This list is the recommended tools for installation. Other versions of the same tool can be used. For example, allen wrenches instead of allen drive sockets.



#2 Phillips Head Screwdriver



#2 Flathead Screwdriver



$\frac{5}{8}$ " Ratchet Wrench  
 $\frac{7}{16}$ " Ratchet Wrench (x2)  
 $\frac{9}{16}$ " Ratchet Wrench



Adjustable Wrench



Deringer Test Cock Wrench



Slip-joint Pliers



$1\frac{5}{16}$ " Socket  
 $1\frac{1}{8}$ " Socket



Wood Block 2" x 4" x 5"  
Wood Block 1" x 2" x 16"



Toothbrush





Ratchet

# Closing Shutoff Valves Prior to Maintenance

## NOTICE

When the threaded portion of the OS&Y stems are fully exposed above the handwheel the shutoff valves are in the open position. Before doing any maintenance be sure to turn the handwheel towards the closed position until the threaded portion of the OS&Y stems have receded down into the bonnet indicating the shutoff valves are in the closed position (A).






1. Slowly rotate shutoff valve #2 handle to the closed position. Stem concealed (A).
2. Slowly rotate shutoff valve #1 handle to the closed position. Stem concealed (A).

# Opening Test Cocks and Bleeding All Pressure from the Line Before Maintenance

*NOTE: valve is still under pressure. When opening test cocks, water will be released. Take precautions to ensure discharging water does not damage the surrounding area/equipment or create an unsafe condition.*

1. **DO NOT OPEN** Main test cock number 1, as it is still subject to line pressure.
2. Using the Deringer™ test cock wrench or a small adjustable wrench open (A) main test cock number 4. (Test cock is open when wrench flats are parallel to water flow through test cock)
3. Deringer 50G/50GX Only: Using a #2 flathead screwdriver open bypass test cock number 2. (Test cock is open when screwdriver slot is parallel to water flow through test cock (B))
4. Using the Deringer test cock wrench or a small adjustable wrench open main test cock number 3.
5. Deringer 50G/50GX Only: Using a #2 flathead screwdriver open bypass test cock number 1.
6. Using the Deringer test cock wrench or a small adjustable wrench open main test cock number 2.





## Removing Access Port Cover Plate

1. Using a  $15/16$ " socket wrench loosen all eight bolts on the access port cover plate (A).
2. Remove bolts and tapered washers and store in a safe place. If lost, tapered bolts must be replaced with like Deringer cover bolts and cannot be substituted with standard bolts.
3. Remove access port cover plate (B). Do not remove access port O-ring (C).






## Removing the First Dual-action™ Check Module

1. Use a  $15/16$ " socket wrench to loosen the check retainer bolts on both sides of the valve body (A). Do not completely remove check retainer bolts from valve body. Loosen the bolts until the ends of the bolts are flush with the inner wall of the valve body (B). Allow easy removal of check modules
2. Insert a flathead screwdriver between the inner valve body and the first check module flange (C), gently push the first check module in the downstream direction until the first check module can easily be removed from the access port by hand.



## Removing the Second Dual-action Check Module


1. Use a  $11/8$ " socket wrench to loosen the check retainer bolts on each side of the valve body (A). Do not completely remove check retainer bolts from valve body. Loosen the bolts until the ends of the bolts are flush with the inner wall of the valve body (B).
2. Insert a flathead screwdriver between the inner valve body and the second check module flange (C), gently push the second check module in the upstream direction until the second check module can easily be removed from the access port by hand.



# Deringer 50G/50GX: Disassembly and Maintenance of Bypass Check Valve


## Part 1

1. Use an adjustable wrench to rotate check cover (A) counterclockwise to remove.
2. Examine cover plate O-ring (B) for damage or fouling.
3. Remove spring (C).
4. Remove check poppet assembly (D) and examine for damage or fouling.
5. Examine seat cage, located inside the check body, for damage or fouling to the sealing seat. Do not remove unless the seat cage is being replaced.
6. Reverse the order of above instructions to reassemble bypass check valve.






## Part 2

1. To replace a damaged red silicone poppet disk, use a #2 phillips head screwdriver to remove the disk retaining screw (A).
2. Remove disk retaining washer (B).
3. Use a flathead screwdriver to remove the gasket from poppet cavity (C).
4. Install new red silicone poppet disk (D).
5. Reverse the order of the above instructions to reassemble check poppet assembly.
6. Reverse the order of the instructions on the previous page to reassemble bypass check assembly.



## Removing Bypass Meter


1. Using the ball valve handles close the #2 bypass ball valve (B) and then #1 bypass ball valve (A). (Ball valve is closed when "T" handle is perpendicular to water flow through ball valve).
2. Using a #2 flathead screwdriver open bypass test cock #2 (D) and then open bypass test cock #1 (C). (Test cock is open when screwdriver slot is parallel to water flow through test cock).
3. Using a large adjustable pliers or wrench unscrew and retract bypass meter coupling nuts (E). Remove the gaskets (F) on both sides of bypass meter.
4. Gently remove bypass meter (G) from line. It is OK if the bypass fittings move slightly during the removal process.
5. Reverse order of above instructions to reinstall bypass meter. Remember install gaskets (F) before threading meter coupling nuts into place.



## Maintenance of First True Seal Check Module

1. Use a #2 phillips head screwdriver to remove tower screws (A) from the first check seat (B) the double torsion spring is captured (C) and does not need to be retained during maintenance.
2. After removing the tower screws (A) examine the elastomer disk (D) and check seat (E) for fouling or damage.
3. Should elastomer disk (D) need replacement unscrew disk retainer screws (F) and remove disk retainer (G). Carefully remove and replace elastomer disk (D). When replacing elastomer disk

- (D) be certain that no air, water or debris is trapped in the clapper (H) cavity behind the elastomer disk (D).
4. Reverse the order of the above instructions to reassemble check.
  - Elastomer disk must be flat in clapper (H) cavity before tightening disk retainer screws (F).
  - Do not cross thread disk retaining screws (F).
  - Check orientation is not important when reattaching the check to the first check seat.



## Maintenance of Second Dual-action Check Module

1. Use a #2 phillips head screwdriver to remove tower screws (A) from the second check seat (B) the double torsion spring is captured (C) and does not to be retained during maintenance.
2. After removing the tower screws (A) examine the elastomer disk (D) and check seat (E) for fouling or damage.
3. Should elastomer disk (D) need replacement unscrew disk retainer screws (F) and remove disk retainer (G). Carefully remove and replace elastomer disk (D). When replacing


- elastomer disk (D) be certain that no air, water or debris is trapped in the clapper (H) cavity behind the elastomer disk (D).
4. Reverse the order of the above instructions to reassemble check.
  - Elastomer disk must be flat in clapper (H) cavity before tightening disk retainer screws (F).
  - Do not cross thread disk retaining screws (F).



### NOTICE


The diagram on the right shows the correct orientation of the second dual-action check module when being re-attached to the seat. In order to maintain the performance of the valve pay attention to the proper orientation of the check module.

Second Check Tower Bosses and Spring Arms Face Down




## Installing First Dual-action Check Module

1. Insert first check module (A) into access port (B) with first check towers (C) pointing downstream. Push first check module (A) upstream into valve sealing ring (D) until check O-ring (E) is resting against valve sealing ring (D). Push first check module (A) into its fully seated position by hand.
2. Alternatively, using a piece of 1"x4" wood cut to 16" length (F) as a lever between the second check seat (F) and the first check towers (C), push the first check module (A) into its fully seated position.
3. Be certain first check module (A) is fully seated and check O-ring (E) is NOT "fish mouthed" or damaged.
4. Now fully tighten the first and second check retaining screws (I).




### ⚠ WARNING

The first check module must be fully seated to ensure retainer screws do not bind against check towers. Binding retainer screws against check towers will result in permanent damage to first check modules.




## Installing Second Dual-action Check Module

1. Insert second check module (A) into access port (B) with second check towers (C) pointing downstream. Push second check module (A) downstream into valve sealing ring (D) until check O-ring (E) rests against valve sealing ring (D). Push second check module (A) into its fully seated position by hand.
2. Alternatively place 2"x4" piece of wood cut to 5" length (F) against the backside of the second check seat ring (G). Using a 1"x4" piece of wood cut to 16" length (H) as a lever between access port wall the 2"x4" (F) gently move the second check module (A) into its fully seated position.
3. Be certain second check module (A) is fully seated and check O-ring (E) is NOT "fish mouthed" or damaged.
4. Tighten the second check retaining screws (I) **ONLY AFTER** the first check module (A) as been installed.



### ⚠ WARNING



The second check module must be fully seated to ensure retainer screws do not bind against check seat. Binding retainer screws against check seat will result in permanent damage to second check modules.



# Maintenance of Relief Valve

## NOTICE



Typically, when a RP device is leaking from the relief valve, a fouled or damaged first check valve is the cause. Make sure the first check valve is functioning properly before assuming there is a problem with the relief valve. If the first check is found to be functioning properly, we recommend cleaning the relief valve piston (B) and seat (C). Use a toothbrush (A) to gently brush away any debris on the relief valve piston (B) and seat (C) that may be preventing the piston (B) from sealing properly against the seat (C). This should return the relief valve to proper working order without disassembly or the use of a repair kit.



## NOTICE


If one is certain that the relief valve requires maintenance proceed as follows.

1. Using a  $\frac{5}{8}$ " box wrench disconnect the relief valve sensing line from the valve body (A).
2. To remove the relief valve from the valve body disconnect the two relief valve mounting bolts (B) using a  $\frac{9}{16}$ " wrench. When removing the relief valve be sure not to drop the top O-ring (C) as the relief valve body uses this O-ring to seal against the valve body.
3. To access the relief valve remove the relief valve cover using two  $\frac{7}{16}$ " wrenches to remove cover bolts (D).
4. Remove the relief valve diaphragm (E) and check the diaphragm for tears, holes or debris (F).




## Maintenance of Relief Valve (continued)

1. Check the rubber seal on the relief valve piston assembly (A) for fouling or damage by making sure the indentation of the seat in the rubber seal is present all the way around. (Confirm the relief valve piston assembly (A) sets flush on relief valve seat (B).)
2. Check relief valve seat (B) for fouling or damage before reinstalling the relief valve piston assembly (A).
3. Once the relief valve is ready to be reassembled, the first step is to reform and reattach the diaphragm to the piston.
4. Move the diaphragm (C) to the fully open position making sure the embossed center is facing up.
5. While holding the diaphragm (C) with both hands, use your thumbs to gently push down on embossed center (D) so the diaphragm collapses into itself and forms a circle so that the bottom of the piston assembly can be inserted into the diaphragm and the embossed center can be pushed into the piston assembly groove.




1. Place the piston assembly (A) into the diaphragm (B), making sure the diaphragm lays flush on the bottom of the piston assembly with no wrinkles or tears in the diaphragm.
2. Place the relief valve spring (C) back onto the relief valve assembly (A) and slide the valve assembly back into the relief valve body (D). Make sure the piston assembly lines up to penetrate hole (E) in top side of relief valve.





## Maintenance of Relief Valve (continued)

1. Using two  $\frac{7}{16}$ " wrenches (A) re-attach the relief valve cover.
2. Making sure the relief valve O-ring (B) is in the groove on the top of the relief valve use a  $\frac{9}{16}$ " wrench to re-attach the two relief valve mounting bolts (C).
3. Use a  $\frac{5}{8}$ " box wrench re-connect the relief valve sensing line to the valve (D).






## Pitot Tube Orientation

1. Before reinstalling the relief valve after maintenance, check to make sure the pitot tube (A) is in the proper orientation. If the pitot tube is **NOT** in the proper orientation the relief valve **WILL LEAK OR DUMP** during flow conditions.
2. The inlet port of the pitot tube (B) at the top of the pitot tube must face directly UPSTREAM toward the #1 shutoff valve. Proper orientation can be confirmed visually by removing the main line valve cover and first check valve (see right).
3. **Note** that the inlet port of the pitot tube (B) is not visible because it is facing directly upstream toward the #1 shutoff valve.
4. A dimple (C) has been provided on the hex wrench portion of the pitot tube in order to visually confirm the proper orientation of the pitot tube from the OUTSIDE of the valve (see right). Note that the dimple (C) is on the same side of the pitot tube as the inlet port of the pitot tube (B) (see right).
5. From the OUTSIDE of the valve the dimple (C) must face directly UPSTREAM toward the #1 shutoff valve. If the dimple (C) of the pitot tube is **NOT** in the oriented UPSTREAM the relief valve **WILL LEAK OR DUMP** during flow conditions






## Installing Access Port Cover

1. It is best to never remove the access port O-ring (A). Should the access port O-ring (A) become dislodged, simply insert it back into access port groove (B).
2. Slide the access port cover (C) into place being certain that access port O-ring (A) does not become dislodged during the process.
3. Insert cover bolts (D) and tapered washers (E) into tapered cover holes (F). Tapered washers (E) must be properly installed with flat side facing up or the access port cover (C) will not seal under pressure.
4. Use  $15/16$ " socket wrench (G) to tighten the 4 center cover bolts (D) alternating from one side of the valve to the other. Then tighten the four corner bolts alternating from one side of the valve to the other.



# Close Test Cocks and Double Check All Closing/Sealing Mechanisms



- Using the Deringer test cock wrench or a small adjustable wrench close main test cocks number 1, 2 and 3 (A). (Test cock is closed when wrench flats on stem are perpendicular to water flow through test cock)
- Deringer 50G/50GX: Using a #2 flathead screwdriver close bypass test cock number 1 and 2 (B). (Test cock is closed when screwdriver slot on stem is perpendicular to water flow through test cock)
- Use the "T" handles to open bypass ball valve number 1 (C) and then open bypass ball Valve number 2 (D). (Ball valve is open when "T" handle is parallel to water flow through ball valve)
- Double check to be certain of the following:
  - All cover bolts are tightened (E)
  - Deringer 50G/50GX: Bypass check valve cover is tightened (F)
  - Deringer 50G/50GX: Bypass meter coupling nuts are tightened (G)





# Open Shutoff Valves to Make Backflow Preventer Functional

1. Slowly rotate shutoff valve #2 handle (A) to the open position. Stem exposed (B).
2. Slowly rotate shutoff valve #1 handle (C) to the open position. Stem exposed (B).



**Limited Warranty:** Ames Fire & Waterworks (the "Company") warrants each product to be free from defects in material and workmanship under normal usage for a period of one year from the date of original shipment. In the event of such defects within the warranty period, the Company will, at its option, replace or recondition the product without charge.

**THE WARRANTY SET FORTH HEREIN IS GIVEN EXPRESSLY AND IS THE ONLY WARRANTY GIVEN BY THE COMPANY WITH RESPECT TO THE PRODUCT. THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED. THE COMPANY HEREBY SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

The remedy described in the first paragraph of this warranty shall constitute the sole and exclusive remedy for breach of warranty, and the Company shall not be responsible for any incidental, special or consequential damages, including without limitation, lost profits or the cost of repairing or replacing other property which is damaged if this product does not work properly, other costs resulting from labor charges, delays, vandalism, negligence, fouling caused by foreign material, damage from adverse water conditions, chemical, or any other circumstances over which the Company has no control. This warranty shall be invalidated by any abuse, misuse, misapplication, improper installation or improper maintenance or alteration of the product.

Some States do not allow limitations on how long an implied warranty lasts, and some States do not allow the exclusion or limitation of incidental or consequential damages. Therefore the above limitations may not apply to you. This Limited Warranty gives you specific legal rights, and you may have other rights that vary from State to State. You should consult applicable state laws to determine your rights. **SO FAR AS IS CONSISTENT WITH APPLICABLE STATE LAW, ANY IMPLIED WARRANTIES THAT MAY NOT BE DISCLAIMED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO ONE YEAR FROM THE DATE OF ORIGINAL SHIPMENT.**



**A WATTS Brand**

**USA: Backflow** T: (978) 689-6066 • F: (978) 975-8350 • AmesFireWater.com  
**USA: Control Valves** T: (713) 943-0688 • F: (713) 944-9445 • AmesFireWater.com  
**Canada:** T: (905) 332-4090 • F: (905) 332-7068 • AmesFireWater.ca  
**Latin America:** T: (55) 4122-0138 • AmesFireWater.com