
PUMP CONTROL VALVE

03/06

980 Series

Model 986 686

- Opens at adjustable rate on pump start-up
- Closes at adjustable rate on pump shut-off
- Limit Switch turns pump off when valve closes
- Hydraulic Check Feature prevents flow reversal
- Solenoid equipped with Manual Operator



STANDARD COMPONENTS

1 - Main Valve (Single Chamber)
2 - Model 22-1 Accelerator Control
3 - Limit Switch
4 - 3-Way Solenoid
5 - Check Valve
6 - Adjustable Closing Speed
7 - Adjustable Opening Speed
X - Isolation Cocks
Y - Y-Strainer

OPTIONS and ACCESSORIES

○ FC - Flo-Clean Strainer
○ L - Dual Limit Switch

8550 Hansen Road • Houston, Texas 77075 • (Ph) 713.943.0688 • (Fx) 713.944.9445 • www.amesfirewater.com