


PUMP CONTROL VALVE

03/06

980 Series

Model **980-16-19**
680-16-19

- Opens at adjustable rate on pump start-up
- Closes at adjustable rate on pump shut-off
- Limit Switch turns pump off when valve closes
- Built-in Mechanical Lift-Check Feature prevents flow reversal
- Solenoid equipped with Manual Operator



STANDARD COMPONENTS

- | | |
|---|------------------------------|
| 1 - Main Valve (Dual Chamber w/ Lift-Check) | 5 - Adjustable Opening Speed |
| 2A - Model 22-1 Accelerator Control | 6 - Adjustable Closing Speed |
| 2B - Model 22-1 Accelerator Control | 7 - Check Valve |
| 3 - Limit Switch | X - Isolation Cocks |
| 4 - 3-Way Solenoid | Y - Y-Strainer |

OPTIONS and ACCESSORIES

- X - Isolation Cocks
- FC - Flo-Clean Strainer
- Y - Y-Strainer (Replaces Flo-Clean)
- L - Dual Limit Switch