




DEEP WELL PUMP CONTROL VALVE

03/06

980 Series

—Model— **985**
685

- Installed on branch of tee off main pumping header
- Normally open construction
- Discharges to atmosphere on pump start-up
- Closes slowly diverting pressure into system during pumping cycle
- Opens slowly on pump shut-off
- Limit Switch turns pump off when valve is fully open
- Adjustable Opening and Closing Speed
- Solenoid equipped with Manual Operator



STANDARD COMPONENTS

- | | |
|-------------------------------|------------------------------|
| 1 - Main Valve (Dual Chamber) | 5 - Adjustable Opening Speed |
| 2 - Limit Switch | X - Isolation Cocks |
| 3 - 4-Way Solenoid | Y - Y-Strainer |
| 4 - Adjustable Closing Speed | |

OPTIONS and ACCESSORIES

- FC - Flo-Clean Strainer
- L - Dual Limit Switch