




PUMP CONTROL VALVE

03/06

980 Series

—Model— **986**
686

- Opens at adjustable rate on pump start-up
- Closes at adjustable rate on pump shut-off
- Limit Switch turns pump off when valve closes
- Hydraulic Check Feature prevents flow reversal
- Solenoid equipped with Manual Operator



STANDARD COMPONENTS

- | | |
|------------------------------------|------------------------------|
| 1 - Main Valve (Single Chamber) | 6 - Adjustable Closing Speed |
| 2 - Model 22-1 Accelerator Control | 7 - Adjustable Opening Speed |
| 3 - Limit Switch | X - Isolation Cocks |
| 4 - 3-Way Solenoid | Y - Y-Strainer |
| 5 - Check Valve | |

OPTIONS and ACCESSORIES

- FC - Flo-Clean Strainer
- L - Dual Limit Switch