

Series 900

Reduced Pressure Zone Assemblies

Size $\frac{3}{4}$ " – 2"

Repair Kits

When ordering specify Ordering Code, Kit No., and Valve Size.

ORDERING CODE	KIT NO.	SIZE
Complete Repair Kits		
0881240	45 BFP-RK	$\frac{3}{4}$ ", 1", 1 $\frac{1}{4}$ "
0881263	47 BFP-RK	1 $\frac{1}{2}$ ", 2"

Kit consists of: inlet adapter gasket, first check valve assembly, with spring and O-ring, second check valve spring, two union nut gaskets, relief valve spring, second check valve assembly, stem O-ring, maintenance tool and silicone grease.

Rubber Parts Kits


FREE*	0881241	46 BFP-RK	$\frac{3}{4}$ ", 1", 1 $\frac{1}{4}$ "
	0881264	48 BFP-RK	1 $\frac{1}{2}$ ", 2"

Kit consists of: molded disc and piston O-ring.

Relief Valve Seat and Seal Kits

0881245	34 BFP-RK	$\frac{3}{4}$ ", 1", 1 $\frac{1}{4}$ "
0881275	35 BFP-RK	1 $\frac{1}{2}$ ", 2"


Kit consists of: relief valve seat and O-ring.



NOTICE

Before reassembly, grease Relief Valve Seat orifice, Piston Bore and Piston O-ring. Use silicone base grease.

Service of these sizes require proper factory maintenance tool kit (see below).



*The wetted surface of this product contacted by consumable water contains less than 0.25% of lead by weight.