WiFi Snow Melting Control 670

670 Sub 32°F Temperature Usage Warming up B36 Melt mode is on. The system is warming up the slab.	10:46	
670 grad grad grad grad grad grad grad grad	<	C :
<text><text><section-header><text><text><text><text><text><text></text></text></text></text></text></text></section-header></text></text>	670	^{Slab} 32 °F
Warming up 366 Matt mode is on. The system is warming up the slab.	Temperature	Usage
Warming up a b b b b b b b b b b b b b b b b b b b		
Warming up B B B C C C C C C C C		
Babe Met mode is on. The system is warming up the slab. () Want to set your device Manual Stap	Warming up	
Meit mode is on. The system is warming up the slab. (1) How to set your device Manual Stop Manual Start	36	
The system is warming up the slab. (1) How to set your device Manual Stop Manual Start	Melt mode is on.	
How to set your device Manual Stop Manual Start	The system is warming up the slab.	
How to set your device Manual Stop Manual Start		
How to set your device Manual Stop Manual Start		
Manual Stop Manual Start	(i) How to	set your device
Manual Stop Manual Start		
	Manual Stop	Manual Start

Get Connected

The WiFi Snow Melting Control 670 operates hydronic and electric heating equipment designed to melt snow and/or ice from roads and walkway surfaces. The control works with the tekmar Snow/Ice Sensor 090 or Snow Sensor 095 to automatically detect snow or ice and operates a single boiler, steam valve, or electric cable to supply heat to the slab. Boiler return protection is provided to non-condensing boilers using a mixing valve or variable speed injection mixing pump. The Watts® Home mobile application allows for remote operation and monitoring of the snow melting system from anywhere in the world.

One Snow Melting Control for any Application

- Compatible with modulating, one-stage and two-stage boilers
- Mixing options include floating action, variable speed injection, 0-10 V and 4-20 mA
- Includes tekmarNet[®] communication for full system integration including options for boiler staging and zoning

Featuring the Best in Snow Melting Control

- Mobile app for iOS and Android
- Automatic software updates
- Automatic snow/ice detection
- Supports both inslab & retrofit aerial sensors (not included)
- Supports multiple zones with priority
- Idling
- Auto Storm
- Warm Weather Shut Down
- Cold Weather Cut Off
- EconoMelt
- Slab Protection
- Tandem Snow/Ice Detection
- Equipment exercising

Works with the Watts[®] Home Mobile App





tekmarControls.com

Better Control Better Systems

Sample Application Drawings

Hydronic Boiler and Mixing

A snow melting system is heated using a hydronic boiler and mixing valve. When snow or ice is detected, the control operates the boiler and mixing valve to heat the slab surface to the melting temperature. The mixing valve protects the boiler from damage caused by cold return temperatures.





Steam-to-Glycol Heat Exchanger

A snow melting system is heated using a modulating steam valve and steam-to-glycol heat exchanger. When snow or ice is detected, the control modulates the steam valve position to heat the slab surface to the melting temperature.

Electric

A snow melting system is heated using electric cables. When snow or ice is detected, the control activates an electrical contactor, which in turn energizes the electric cables to heat the slab surface to the melting temperature.



Scan to learn more about tekmar WiFi Snow Melting Control 670



T: 1-800-438-3903 • Fax: (250) 984-0815 tekmarControls.com